


BINQ TILT & TURN WINDOW 140mm INTERNAL REVEAL SECTION DETAIL


BINQ TILT & TURN WINDOW 140mm INTERNAL REVEAL PLAN DETAIL




Inside









Inside

General Notes:

- The information provided here are guidelines only. Always adhere to Australian standards / BCA
- The installation and correct operation of these units in the installed situation is the responsibility of the installer. This includes but not limited to the correct flashing of doors and windows.
- Screw fixings must be used, DO NOT use nails
- The installed units must be plumb, square and level to a laser level. DO NOT use a conventional spirit level
- Check for smooth operation
- Check for even an even gap between sash and jamb
- Operate sash strictly per operating instructions provided
- Sash hardware is adjustable
- Adjust sash per instructions provided if required
- Check all gaskets are seated correctly
- Decouple and couple sash strictly per instructions provided. <u>Incorrect</u> <u>coupling may result in</u> serious injury to operator

